

SWISSTEN 

**BLUETOOTH TWS EARPHONES
SWISSTEN SONIC**



User guide



OPERATION INSTRUCTIONS:

- Power on: Open the charging box, and the earphones will automatically turn on.
- Power off: Put the earphones in the charging box and close the box cover to shut down the device.
- Play / Pause: Click on the left or right earphone.
- Next song: Double clicks on the right earphone
- Previous song: Double clicks on the left earphone.
- Volume UP: Three clicks on the right earphone.
- Volume DOWN: Three clicks on the left earphone.
- Voice Assistant: Long press on the right or left earphone for 2 seconds.
- Answer the call: Click on the left or right earphone.
- Reject call: Long click on the left or right earphone.
- Pairing: Open the charging box and take out the earphones to enter pairing mode.
- Connect to the "SWISSTEN Sonic" Bluetooth device.

LED INDICATOR STATUS:

- Earphone removal / insertion into the charging box: The indicator light flashes.
- Charging the box: The indicator flashes a red color until it is fully charged.
- Charging box fully charged: The indicator light will shine.

BLUETOOTH CONNECTION STEPS:

1. Please control the distance between the SWISSTEN Sonic earphones and your smartphone (or other device with bluetooth) within 1 meter. (More closer is better).
2. Open the charging box and take out the earphones to enter pairing mode. (Do not close the charging box cover during the connection process.)
3. Connect to the "SWISSTEN Sonic" Bluetooth device.

NOTES:

- When you remove the earphones from charging box, make sure that the left and right earphones are connected.
- The charging box needs to have enough power. If is not possible to connect duet the low battery, plug the charger into the box for at least one hour.

WARNING!

1. Never use corrosive cleaning agents to clean this product.
2. Do not allow this product to come close to fire sources, such as cooking stoves, etc.
3. Do not expose this product to direct sunlight for a long time to avoid high temperatures.
4. Do not dispose of this product in fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. Do not use this product in the rain.
7. If you do not plan to use this product for a long period of time, please follow these steps:
 - Store earphones in a dry environment.
 - Also please charge the earphones at least once a month to extend the life.
 - Avoid extreme temperatures and dust.

Specifications:

Chip: BLUETRUM 5656
Bluetooth version: 5.3
Working range: Up to 10m
Frequency response: 20Hz-20kHz
Wireless frequency: 2,402 - 2,480GHz
Earbuds batteries: Each 30mAh
Charging box capacity: 230mAh
Charging voltage: 5V DC 1A / 5W
Charging time: 2 hours
Standby time: 35 hours
Talking time: 3.5 hours (80% volume)
Music time: 6 hours (80% volume)

The company GAMACZ.CZ s.r.o., declares that this radio equipment is in compliance with Directive 2014/53/EU. The consolidated text of the EU statement of conformity is available at the following internet address: www.swissten.com

SWISSTEN 

**BLUETOOTH TWS SLUCHÁTKA
SWISSTEN SONIC**



Uživatelská příručka



NÁVOD K OBSLUZE:

- Zapnutí: Otevřete nabíjecí box a sluchátka se automaticky zapnou.
- Vypnutí: Vložte sluchátka do nabíjecího boxu a zavřete kryt boxu pro vypnutí zařízení.
- Přehrávání / Pozastavit: Klikněte na levé nebo pravé sluchátko.
- Další skladba: Dvojité kliknutí na pravé sluchátko.
- Předchozí skladba: Dvojité kliknutí na levé sluchátko.
- Zvýšení hlasitosti: Tři kliknutí na pravé sluchátko.
- Snížení hlasitosti: Tři kliknutí na levé sluchátko.
- Hlasový asistent: Dlouhé stisknutí pravého nebo levého sluchátka po dobu 2 sekund.
- Přijmout hovor: Klikněte na levé nebo pravé sluchátko.
- Odmítnutí hovoru: Dlouhé stisknutí levého nebo pravého sluchátka.
- Párování: Otevřete nabíjecí box a vyjměte sluchátka, abyste vstoupili do režimu párování.
- Připojte se k zařízení Bluetooth „SWISSTEN Sonic“.

STAV LED INDIKÁTORU:

- Vymíti / vložení sluchátek do nabíjecího boxu: Kontrolka sluchátek bliká.
- Nabíjení boxu: Indikátor bliká červeně, dokud není plně nabitý.
- Nabíjecí box plně nabitý: Kontrolka bude svítit.

PŘIPOJENÍ BLUETOOTH:

1. Zkontrolujte prosím, zda je vzdálenost mezi sluchátky SWISSTEN Sonic a vašim chytrým telefonem (nebo jiným zařízením s bluetooth) kratší než 1 metr. (Čím blíž, tím líp)
2. Otevřete nabíjecí box a vyjměte sluchátka, abyste vstoupili do režimu párování. (Nezavírejte kryt nabíjecího boxu během procesu připojení.)
3. Připojte se k Bluetooth zařízení „SWISSTEN Sonic“.

Upozornění

- Když vyjměte sluchátka z nabíjecího boxu, ujistěte se, že jsou připojena levá a pravá sluchátka.
- Nabíjecí box musí mít dostatek energie. Pokud není možné připojit duet, low baterie, zapojte nabíječku do krabice alespoň na jednu hodinu.

Varování

1. K čištění tohoto produktu nikdy nepoužívejte korozivní čisticí prostředky.
 2. Nedovolte, aby se tento výrobek přiblížil k ohni.
 3. Nevystavujte tento výrobek přímému slunečnímu záření na dlouhou dobu, aby nedošlo k vysoké teplotě.
 4. Nevhazujte tento výrobek do ohně, aby nedošlo k výbuchu.
 5. Nepokoušejte se tento výrobek rozebrat za účelem jakýchkoli oprav.
 6. Nepoužívejte tento výrobek v dešti.
 7. Pokud neplánujete používat tento produkt po delší dobu, postupujte podle následujících kroků:
 - Skladujte sluchátka v suchém prostředí.
 - Také prosím nabíjejte sluchátka jednou měsíčně, abyste prodloužili životnost.
- Vyhýnejte se extrémním teplotám a prachu.

Specifikace:

Čip: BLUETRUM 5656
Verze Bluetooth: 5.3
Bluetooth dosah: Až 10 metrů
Frekvenční odezva: 20Hz-20kHz
Bezdrátová frekvence: 2,402 - 2,480 GHz
Baterie ve sluchátkách: Každá 30 mAh
Kapacita nabíjecího boxu: 230mAh
Nabíjecí napětí: 5V DC 1A / 5W
Doba nabíjení: 2 hodiny
Provozní doba: 35 hodin
Doba hovoru: 3.5 hodiny (80 % hlasitosti)
Doba přehrávání hudby: 6 hodin (80% hlasitost)

Společnost GAMACZ.CZ s.r.o., tímto prohlašuje, že toto rádiové zařízení je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na internetové adrese: www.swissten.com

Front side

Back side