


SWISSTEN 

**BLUETOOTH TWS EARPHONES
FOCUS ANC**



User guide



OPERATION INSTRUCTIONS:

- Power on: Open the charging box, and the earphones will automatically turn on
- Power off: Place the headphones in the charging box and close the charging box cover to shut down the device.
- Play / Pause: Click on the left or right earphone.
- Previous song: Three clicks on left or right earphone.
- Next song: Double click on left or right earphone.
- Voice Assistant: Press and hold for 4 seconds on left earphone.
- Answer a call: Click on the left or right earphone.
- Reject call: Press and hold on left or right earphone.
- Transparency mode / ANC mode / Normal mode switching: Press and hold on right earphone for 4 seconds to cycle switching 3 different modes.
- Pairing: Open the charging box and the earphones will automatically enter pairing mode. Connect to „SWISSTEN FOCUS“ Bluetooth device.

LED INDICATOR STATUS:

- When the battery is low: The indicator flashes orange
- When the battery is full: The indicator flashes white
- Closing the charging box: The white light shine for 4 seconds and then turns off
- Opening the charging box: The white light shine for 6 seconds and then turns off
- Earphone removal / insertion into the charging box: The white light flashes once
- Charging the charging box: The orange light shine until its fully charged
- Charging box fully charged: The white light will turn off automatically after 8 seconds

BLUETOOTH CONNECTION STEPS:

- 1.Please control the distance between the Swissten earphones and your smartphone (or other device with bluetooth) within 1 meter. (Closer is better).
- 2.Open the earphones box to connect with your device.(Do not close the charging box cover during the connection process.)
- 3.On your device start pairing with bluetooth device „SWISSTEN FOCUS“.
- 4.When you remove the earphones from charging box, make sure that the left and right earphones are connected.
- 5.The charging box needs to have enough power. If is not possible to connect due to low battery, plug the charger into the box for at least one hour.

WARNING!

- 1.Never use corrosive cleaning agents to clean this product.
- 2.Do not allow this product to come close to fire sources, such as cooking stoves, etc.
- 3.Do not expose this product to direct sunlight for a long time to avoid high temperatures.
- 4.Do not dispose of this product in fire to avoid explosion.
- 5.Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
- 6.Do not use this product in the rain.
- 7.If you do not plan to use this product for a long period of time, please follow these steps:
 - Store earphones in a dry environment.
 - Also please charge the earphones at least once a month to extend the life.
 - Avoid extreme temperatures and dust.

Specifications:


Chip: JL7003D4
Bluetooth version: 5.3
Working range: up to 10m
Frequency response: 20Hz - 20kHz
Wireless frequency: 2,402-2,480GHz
Earbuds batteries: each 40 mAh
Charging box capacity: 400mAh
Charging voltage: 5V DC 1A
Charging time: 2 hours
Standby time: 28 hours
Talking time: 3.5 hours (80% volume)
Music time: 6 hours (80% volume)
Music time with ANC: 5 hours (80% volume)

SWISSTEN 

**BLUETOOTH TWS SLUCHÁTKA
FOCUS ANC**



Uživatelská příručka



NÁVOD K OBSLUZE:

- Zapnutí: Otevřete nabíjecí box a sluchátka se automaticky zapnou.
- Vypnutí: Vložte sluchátka do nabíjecího boxu a zavřete kryt nabíjecího boxu.
- Přehrávání/pozastavení: 1x klepněte na levé nebo pravé sluchátko.
- Předchozí skladba: 3x klepněte na levé nebo pravé sluchátko.
- Další skladba: 2x klepněte na levé nebo pravé sluchátko.
- Hlasový asistent: Stiskněte a podržte prst 4 sekundy na levém sluchátku.
- Odpověď na hovory: Klepněte na levé nebo pravé sluchátko.
- Odmítnutí hovoru: Stiskněte a podržte levé nebo pravé sluchátko.
- Přepínání režimů: ANC / Propustného / Normálního: Stisknutím a podržením pravého sluchátka podobu 4 sekund.
- Párování: Sluchátka se automaticky přepnou do režimu párování: Otevřete nabíjecí box a sluchátka se automaticky přepnou do režimu párování. Připojte se k zařízení Bluetooth "SWISSTEN FOCUS".

STAV LED INDIKÁTORU:

- Pokud je baterie vybitá: Indikátor bliká oranžově
- Pokud je baterie plná: Indikátor bliká bíle
- Při zavření nabíjecího boxu: Bílé světlo svítí po dobu 4 sekund a poté zhasne.
- Při otevření nabíjecího boxu: Bílé světlo svítí 6 sekund a poté zhasne.
- Vymnutí / vložení sluchátka do nabíjecího boxu: Bílé světlo jednou blikne.
- Nabíjení nabíjecího boxu: Oranžové světlo svítí, dokud není plně nabit.
- Nabíjecí box je plně nabit: Bílé světlo automaticky zhasne po 6 sekundách.

PŘIPOJENÍ BLUETOOTH:

1. Dodržte vzdálenost mezi sluchátký SWISSTEN FOCUS a vašim smartphonem (nebo jiným zařízením s bluetooth) do 1 metru.
2. Otevřete krabičku sluchátek (během procesu připojení nezapínejte kryt nabíjecí krabičky).
3. Na svém zařízení spusťte párování se zařízením bluetooth "SWISSTEN FOCUS".
4. Když vyjmete sluchátka z nabíjecí krabičky, ujistěte se, že jsou levé a pravé sluchátko připojeny.
5. Nabíjecí krabička musí mít dostatek energie. Pokud není možné připojit sluchátka, může být příčinou vybitá baterie. Připojte nabíječku k boxu alespoň na jednu hodinu.

Upozornění

1. K čištění tohoto výrobku nikdy nepoužívejte žíravé čisticí prostředky.
2. Nedovolte, aby se tento výrobek přiblížil ke zdrojům ohně, jako jsou sporáky apod.
3. Nevystavujte tento výrobek dlouhodobě přímému slunečnímu záření, abyste ho nevystavovali vysokým teplotám.
4. Nevyhazujte tento výrobek do ohně, aby nedošlo k výbuchu.
5. Nepokoušejte se tento výrobek rozebrat za účelem provádění jakýchkoli úprav.
6. Nepoužívejte tento výrobek při dešti.
7. Pokud neplánujete tento výrobek používat po delší dobu, postupujte podle následujících pokynů:
 - Sluchátka skladujte v suchém prostředí.
 - Také prosím nabíjejte sluchátka alespoň jednou za měsíc, abyste prodloužili jejich životnost.
 - Vyhnete se extrémním teplotám a prachu.

Specifikace:

Čip: JL7003D4
Verze Bluetooth: 5.3
Pracovní dosah: až 10 m
Frekvence: 2,402-2,480GHz
Frekvenční rozsah: 20Hz - 20kHz
Kapacita baterii sluchátek: Každé 40 mAh
Kapacita baterie nabíjecího boxu: 400 mAh
Vstup nabíjecího boxu: 5V DC 1A
Doba nabíjení: 2 hodiny
Provozní doba: 28 hodin
Doba hovoru: 3.5 hodiny (80% hlasitost)
Doba přehrávání hudby: 6 hodin (80% hlasitost)
Doba přehrávání hudby s ANC: 5 hodin (80% hlasitost)